



NOTES:

1. PRIOR TO INSTALLATION OF SEAM TAPE, APPLY PRIMER TO SEAM AREAS.
2. SEAM TAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (25 mm) AT THE ENDS OF EACH CUT PIECE. APPLY LAP SEALANT AT TAPE OVERLAPS AS SHOWN ABOVE.
3. 6" (150 mm) WIDE PEEL & STICK UNCURED FLASHING MAY ALSO BE CENTERED OVER THE INTERSECTING POINT OF THE LEADING EDGES OF THE FIELD SEAM INTERSECTION.
4. LAP SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED EPDM MEMBRANE.

**WBRC-2.2
MEMBRANE SEAM WITH SEAM TAPE**

