



NOTES:

1. LOCATE C-9 TERMINATION ABOVE ANTICIPATED WATER LEVEL.
2. FOR CORNER APPLICATIONS, SEE DETAIL WFC-15.
3. IF A CONTINUATION OF THE DECK MEMBRANE IS TO BE USED AS WALL FLASHING, REFER TO DETAIL WFC-12.3 OR WFC-12.4.
4. APPLY LAP SEALANT ALONG THE EDGE OF THE MEMBRANE SPICE (UNDER THE 6" x 6" T-JOINT COVER) COVERING THE EXPOSED SPlice TAPE 2" (50 mm) IN EACH DIRECTION FROM THE SPICE INTERSECTION.
5. 6" (150 mm) WIDE PEEL & STICK UNCURED EPDM FLASHING MAY ALSO BE CENTERED OVER FIELD SPICE AT ANGLE CHANGE.
6. PRIOR TO INSTALLATION OF WHITE PEEL & STICK SEAM TAPE, APPLY WEATHERBOND TPO PRIMER TO THE SPICE AREA.

WFC-12.1
PARAPET / CURB

WEATHERBOND™

©2009 WEATHERBOND