



NOTES:

1. LOCATE DETAIL WFC-9 TERMINATION ABOVE ANTICIPATED WATER LEVEL.
2. FOR CORNER APPLICATION, SEE DETAIL WFC-15.
3. 6" (150 mm) WIDE QUICK APPLIED UNCURED EPDM FLASHING MAY ALSO BE CENTERED OVER FIELD SPLICE AT ANGLE CHANGE AND SPLICE INTERSECTIONS.
4. WB TPO PRIMER MUST BE APPLIED TO MEMBRANE SURFACE PRIOR TO APPLYING QUICK APPLIED FLASHING.
5. LAP SEALANT MUST BE APPLIED ALONG FLASHING OVERLAPS AS SHOWN ABOVE.
6. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE 6" X 6" T-JOINT COVER) COVERING THE EXPOSED SPLICE TAPE 2" (50 mm) IN ALL DIRECTIONS FROM THE SPLICE INTERSECTION.

WFC-12.2

PARAPET / CURB CONTINUOUS TPO

WEATHERBOND™

©2009 WEATHERBOND