



1. PRIOR TO INSTALLATION OF P&S SEAM TAPE, APPLY TPO PRIMER TO SPLICE AREAS.

2. P&S SEAM TAPE IS TO BE OVERLAPPED A MINIMUM OF 1" (25 mm) AT THE ENDS OF EACH CUT PIECE. APPLY LAP SEALANT AT TAPE OVERLAPS AS SHOWN ABOVE.

3. 6" (150 mm) WIDE PEEL & STICK UNCURED FLASHING MAY ALSO BE CENTERED OVER THE INTERSECTING POINT OF THE LEADING EDGES OF THE FIELD SPLICE INTERSECTION.

4. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE 6" X 6" T-JOINT COVER) COVERING THE EXPOSED SPLICE TAPE 2" (50 mm) IN ALL DIRECTIONS FROM THE SPLICE INTERSECTION.

5. CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF TPO MEMBRANE.

WFC-2.2

MEMBRANE SPLICE WITH PEEL & STICK (P&S) SEAM TAPE

WEATHERBOND™

©2009 WEATHERBOND