



NOTES:

1. FOR EXPANSION JOINT INTERSECTIONS AND INTERSECTIONS BETWEEN EXPANSION JOINTS TO WALL OR EDGING, USE 3 LAYERS OF UNCURED EPDM FLASHING WITH EACH LAYER 3" (75 mm) LARGER THAN PREVIOUS LAYER IN ALL DIRECTIONS.
2. WIDTH OF JOINT SHALL BE A MINIMUM OF 3/4" (19 mm) AND SHALL NOT EXCEED 3" (75 mm).
3. WEATHERBOND TPO PRIMER MUST BE APPLIED TO BACK SIDE OF DECK MEMBRANE PRIOR TO COMPLETING SPLICE TO PEEL & STICK RPS.

WFC-3.6

DECK TO DECK EXPANSION JOINT (RUSS)

**WEATHERBOND™**

©2009 WEATHERBOND