



NOTES:

1. ALL COMPLETE OUTSIDE AND INSIDE CORNERS REQUIRE TWO CORNER APPLICATIONS OF UNCURED EPDM FLASHING AS PER DETAIL WFC-15.
2. WIDTH OF JOINT SHALL BE A MINIMUM OF 3/4" (19 mm) AND SHALL NOT EXCEED 2" (50 mm).
3. WEATHERBOND TPO PRIMER MUST BE APPLIED TO MEMBRANE SURFACE PRIOR TO APPLYING PS CURED COVER STRIP.
5. LAP SEALANT MUST BE APPLIED ALONG PS CURED COVER STRIP AT FLASHING OVERLAPS AS SHOWN ABOVE.
6. APPLY LAP SEALANT ALONG THE LEADING EDGE OF THE MEMBRANE SPLICE (UNDER THE 6" X 6" T-JOINT COVER) COVERING THE EXPOSED SPLICE TAPE 2" (50 mm) IN ALL DIRECTIONS FROM THE SPLICE INTERSECTION.

WFC-3.7

DECK TO WALL EXPANSION JOINT

WEATHERBOND™

©2009 WEATHERBOND