



- NOTES:
1. FOR ALTERNATE CURB FLASHING REFER TO DETAIL WFC-12.3 OR WFC-12.4.
  2. IF VERTICAL SPUCE IS NOT LOCATED AT CORNER, 6" (150 mm) WIDE PEEL & STICK UNCURED FLASHING MUST BE CENTERED OVER FIELD SPUCE AT ANGLE CHANGE.
  3. FASTENING PLATES MAY BE INSTALLED VERTICALLY.
  4. APPLY TPO PRIMER PRIOR TO INSTALLING P&S SEAM TAPE.
  5. CUT EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED MEMBRANE.

WFC-5.2  
 PEEL & STICK CURB FLASHING