



NOTES:

1. IF FASTENER PENETRATES METAL COUNTERFLASHING, USE WASHER, APPLY WATER CUT-OFF MASTIC OR CAULK FASTENER HEAD.

WFC-9.3

COUNTERFLASHING TERMINATION

**WEATHERBOND**<sup>TM</sup>

©2009 WEATHERBOND