



NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING BEFORE INSTALLING FIELD-FABRICATED PIPE SEAL.
2. TEMPERATURE OF PIPE MUST NOT EXCEED 180° F (82° C).
3. PEEL & STICK UNCURED EPDM FLASHING WRAPPED AROUND PIPE SHALL HAVE 3" (75 mm) MINIMUM MEMBRANE SPLICE.
4. FLASHING WRAPPED AROUND PIPE SHALL HAVE 3" (75 mm) MINIMUM MEMBRANE SPLICE.
5. INSTALL A MINIMUM OF FOUR 2 ³/₈" SEAM FASTENING PLATES WITH A DIAMETER UP TO 6" (150 mm). ADDITIONAL SEAM FASTENING PLATES WILL BE REQUIRED FOR PIPES GREATER THAN 6" (150 mm) IN DIAMETER AND SHALL BE SPACED 12" (300 mm) ON CENTER.
6. WEATHERBOND TPO PRIMER MUST BE APPLIED TO MEMBRANE SURFACE PRIOR TO APPLYING PEEL & STICK CURED COVER STRIP (OVER FASTENING PLATES) AND PEEL & STICK UNCURED EPDM FLASHING AT THE PIPE.

WFMA-14

FIELD FABRICATED PIPE SEAL

WEATHERBOND™

©2009 WEATHERBOND