



WB 2 3/8" SEAM FASTENING
 PLATE MAX. 12" (300 mm) O.C.
 POSITIONED ALONG CENTER
 LINE OF RUSS

6" (150 mm) WIDE MEMBRANE
 SPLICE

6', 8', 10' OR 12' WIDE
 WB PRO TPO MEMBRANE

10" PS RUSS

INSULATION (BY OTHERS)
 3'-6" (1000 mm) MIN.
 4'-6" (1300 mm) MAX.

NOTES:

1. RIDGE MEMBRANE ATTACHMENT IS ONLY REQUIRED WHEN ROOF SLOPE EXCEEDS 3" TO THE HORIZONTAL FOOT (75 mm/300 mm).
2. REINFORCED TPO MEMBRANE SHALL BE INSTALLED PARALLEL WITH SLOPE (OVER RIDGE LINE) AS SHOWN.
3. FOR PROPER MEMBRANE ATTACHMENT AND SPLICING, REFER TO APPLICABLE WFMA-2 DETAIL.

WFMA-22.1

RIDGE MEMBRANE ATTACHMENT

WEATHERBONDTM

©2009 WEATHERBOND