

1

FASTEN MEMBRANE AND FLASH CURB OR WALL WITH CURED EPDM MEMBRANE FOLLOWING STANDARD PROCEDURES USING BONDING ADHESIVE AND P&S SEAM TAPE AT MEMBRANE SPLICE.

2

CENTER FOLD LINE
PEEL & STICK UNCURED EPDM FLASHING 6"x6" (152X152mm)

USE PRE-CUT T-JOINT COVERS OR CUT A 6"x6" (152X152mm) & 12"x12" (305X305mm) SECTION OF PEEL & STICK UNCURED EPDM FLASHING AND ROUND CORNERS

3

EPDM PRIMER

CLEAN THE DRY SPLICE AREA OF THE EPDM WITH EPDM PRIMER; APPLY LAP SEALANT 1/2" (13mm) MIN. FROM THE CURB AS SHOWN IN STEP 4.

4

POLY FILM
LAP SEALANT
1/2" EACH DIRECTION

AFTER APPLYING LAP SEALANT, REMOVE & REPLACE POLY BACKING ON FLASHING. FOLD 6"x6" FLASHING IN HALF WITH ROUNDED PORTION TURNED UP. CENTER ON CORNER & FIRMLY PRESS AGAINST VERTICAL SURFACE

5

ROLL & CREASE FLASHING TIGHTLY INTO ANGLE CHANGE & FIRMLY ROLL FLASHING ONTO THE DECK MEMBRANE

USE HEAT GUN TO WARM THE FLASHING IN COLD WEATHER

6

AFTER ADHERING, ROLL WITH A TWO INCH WIDE STEEL HAND ROLLER. PAY PARTICULAR ATTENTION TO THE STEP OFFS AND ANGLE CHANGES

7

ROLL STEP OFFS AND ANGLE CHANGES

8

CLEAN THE SPLICE AREA WITH EPDM PRIMER. INSTALL THE 12"x12" SECTION OF PEEL & STICK UNCURED EPDM FLASHING TO EXTEND A MINIMUM 2" BEYOND THE PREVIOUSLY APPLIED 6"x6" FLASHING (STEPS 4-6).

9

SEAL ALL EDGES WITH LAP SEALANT AS SHOWN