



NOTES:

1. REMOVE ALL LEAD AND OTHER FLASHING BEFORE INSTALLING PEEL & STICK PIPE SEAL.
2. PIPE SEAL MUST HAVE INTACT RIB AT TOP EDGE, REGARDLESS OF PIPE DIAMETER.
3. DECK FLANGES OF THE MOLDED PIPE SEAL SHALL NOT BE OVERLAPPED, CUT OR APPLIED OVER ANY ANGLE CHANGE.
4. (60-MIL) (1.52mm) EPDM OR 20" (508mm) PEEL & STICK CURED EPDM FLASHING.
5. AT THE CUT IN THE FIELD MEMBRANE, FLASHING OVERLAY MUST EXTEND 3" (76mm) BEYOND THE MOLDED PIPE FLASHING FLANGE ON 3 SIDES AND WITHIN 1" (25mm) OF THE EDGE OF THE FIELD MEMBRANE, AS SHOWN.
6. CENTER 9" (229mm) WIDE PEEL & STICK UNCURED EPDM FLASHING OVER THE MEMBRANE SPLICE EDGE AND EXTEND 3" (76mm) BEYOND THE MEMBRANE OVERLAY, AS SHOWN.
7. SEAL ALL EDGES WITH CONTINUOUS LAP SEALANT.