



NOTES:

1. FASTENERS MUST PENETRATE INTO WOOD OR METAL STUDS, WHERE WALL IS BUILT WITH STUDS.
2. HPWX FASTENERS ARE REQUIRED OVER STEEL AND WOOD DECKS.