





ANGLE CHANGE SECUREMENT

NOTES:

- 1. WEATHERBOND TPO MEMBRANE REQUIRES WEATHERBOND TPO BONDING ADHESIVE AND WEATHERBOND PVC MEMBRANE REQUIRES WEATHERBOND PVC BONDING ADHESIVE.
- 2. HPWX FASTENERS AND RhinoBOND PLATES ARE REQUIRED OVER STEEL AND WOOD DECKS. FOR WIND SPEEDS GREATER THAN 72 MPH PLEASE CONTACT WEATHERBOND FOR REQUIRED FASTENING ENHANCEMENTS.



ANGLE CHANGE SECUREMENT METHOD WITH RhinoBond PLATES

WEATHERBOND RhinoBond

RB-2