



- NOTES:
1. TPO MEMBRANE PRIMER MUST BE APPLIED ON THE BACK SIDE OF TPO MEMBRANE, PRIOR TO ADHERING THE MEMBRANE TO PEEL & STICK RPS.
  2. HPW-PURLIN FASTENER MAX. 12" (30cm) O.C.
  3. 1/2" (1.5cm) MIN.



MEMBRANE ATTACHMENT

HIGH DENSITY RECOVER BOARD  
 IN-FILL INSULATION  
A 0 SEE NOTE(S)

METAL RETROFIT  
MR | T2.1