

## NOTES:

- 1. WHEN WEATHERBOND EXPANSION JOINT SUPPORT IS USED, WIDTH OF JOINT SHALL BE A MINIMUM OF 3/4" (2cm) AND SHALL NOT EXCEED 3" (7.5cm).
- 2. APPROXIMATELY 1/8" (0.5cm) DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED TPO MEMBRANE.
- 3. WHEN USING 60 OR 80 MIL REINFORCED THERMOPLASTIC MEMBRANE, APPLY A 4-1/2" (11cm) DIAMETER THERMOPLASTIC "T-JOINT" COVER AT ALL FIELD SPLICE INTERSECTIONS.
- 4. ROOF MEMBRANE SHALL NOT BE ADHERED OVER THE EXPANSION JOINT SUPPORT OR SPONGE TUBING.



DECK-TO-DECK EXPANSION JOINT → WEATHERBOND FLEECE MEMBRANE

→ FLEXIBLE DASH

→ APPROVED SUBSTRATE

O → SEE NOTE(S)

THERMOPLASTIC WEATHERBOND FLEECE ADHERED

WBF-3.1