



NOTES:

1. FOR TPO, USE 6" (15cm) WIDE PAS COVERSTRIP, FOR PVC USE 6" (15cm) WIDE REINFORCED PVC MEMBRANE, HOT AIR WELD ALL EDGES WITH MIN. 1-1/2" (4cm) PAST FASTENING PLATES

DIMENSIONS	cm		
(A)	6"	15	
(B)	32"	80	MAX.
(C)	12"	30	MAX.



PARAPET FLASHING / NO ADHESION – ANY HEIGHT OPTION

- WEATHERBOND THERMOPLASTIC REINFORCED MEMBRANE
- APPROVED SUBSTRATE
- SEE NOTE

THERMOPLASTIC ROOFING SYSTEM
WBPC-12.6