



PRE-MOLDED OUTSIDE CORNER BEFORE INSTALLATION

NOTES:

1. POSITION FASTENING PLATES 6" (15cm) FROM THE CORNER AND 1/2" TO 1" (1.5 TO 2.5cm) FROM EDGE OF MEMBRANE.
2. APPROXIMATELY 1/8" (0.5cm) DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF WEATHERBOND REINFORCED TPO MEMBRANE.
3. REFER TO WEATHERBOND SPECIFICATIONS FOR ACCEPTABLE FASTENERS AND PLATES.



PRE-MOLDED OUTSIDE CORNER FLASHING

	WEATHERBOND THERMOPLASTIC REINFORCED MEMBRANE
	APPROVED SUBSTRATE
	SEE NOTE

THERMOPLASTIC ROOFING SYSTEM

WBPC-15.4