



NOTES:

1. PRE-CUT 7" X 9" CORNER OR 9" X 9" PEEL & STICK UNCURED EPDM.
2. FOR PROJECTS USING 90-MIL MEMBRANE, INSTALL A 6" T-JOINT COVER PRIOR TO INSTALLING 12" T-JOINT COVER. SEAL TOP LAYER WITH CONTINUOUS LP SEALANT. PER DETAIL [WBRC-15.4](#).
3. A HEAT GUN MUST BE USED WHEN FORMING PEEL & STICK UNCURED EPDM FLASHING IN COLDER TEMPERATURES.