



NOTES:

1. FOR EXPANSION JOINT INTERSECTIONS AND INTERSECTIONS BETWEEN EXPANSION JOINTS TO WALL OR EDGING, USE TWO LAYERS OF PEEL & STICK UNCURED EPCM FLASHING WITH SECOND LAYER 3" (7.5cm) LARGER THAN PREVIOUS LAYER IN ALL DIRECTIONS.
2. ROOF MEMBRANE SHALL NOT BE ADHERED OVER THE EXPANSION JOINT SUPPORT OF SPONGE TUBING.
3. WIDTH OF JOINT SHALL BE A MINIMUM OF 3/4" (2cm) AND SHALL NOT EXCEED 3" (7.5cm) WHEN WEATHERBOND EXPANSION JOINT SUPPORT IS USED.
4. HPWX FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED ON MECHANICALLY FASTENED SYSTEMS OVER STEEL DECKS.



<p>DECK-TO-DECK EXPANSION JOINT</p>	<p>—● EPDM MEMBRANE</p> <p>—● APPROVED SUBSTRATE</p> <p>—● SEE NOTE</p>
---	---

<p>EPDM ROOFING SYSTEM</p>
<p>WBRC-3.1</p>