



NOTES:

1. ALL OUTSIDE AND INSIDE CORNERS REQUIRE TWO COMPLETE CORNER APPLICATIONS OF PEEL & STICK UNCURED EPDM FLASHING AS PER [DETAILS WBRC-15.](#)
2. ROOF MEMBRANE SHALL NOT BE ADHERED OVER THE EXPANSION JOINT SUPPORT OF SPONGE TUBING.
3. WIDTH OF JOINT SHALL BE A MINIMUM OF 3/4" (2cm) AND SHALL NOT EXCEED 2" (5cm) WHEN WEATHERBOND EXPANSION JOINT SUPPORT IS USED.
4. USE [DETAIL WBRC-2.3](#) FOR EPDM MEMBRANE SPLICES AT ANGLE CHANGES.
5. HPWX FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED ON MECHANICALLY FASTENED SYSTEMS OVER STEEL DECKS.



DECK-TO-WALL EXPANSION JOINT	—●— EPDM MEMBRANE —●— APPROVED SUBSTRATE —●— SEE NOTE
	0

EPDM ROOFING SYSTEM
WBRC-3.2