




NOTES:

1. PEEL & STICK RPS MAY BE INSTALLED INTO THE STRUCTURAL DECK. ON MECHANICALLY-FASTENED ROOFING SYSTEMS, HPWX FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
2. USE [DETAIL WBRC-2.3](#) FOR EPDM MEMBRANE SPLICES AT ANGLE CHANGES.
3. SEAL FASTENERS BY APPLYING WATER CUT-OFF MASTIC UNDER THE COUNTER-FLASHING, OR USING EPDM WASHERS, OR CAULKING THE FASTENERS HEAD.
4. ALL OUTSIDE AN INSIDE CORNER REQUIRE TWO COMPLETE CORNER APPLICATIONS OF PEEL & STICK UNCURED EPDM FLASHING AS PER DETAILS [WBRC-15](#).



SHEAR/EXPANSION COVER	 EPDM MEMBRANE
	 APPROVED SUBSTRATE
	 SEE NOTE

EPDM ROOFING SYSTEM
WBRC-3.3