


## NOTES:

- RIDGE MEMBRANE ATTACHMENT IS ONLY REQUIRED WHEN ROOF SLOPE EXCEEDS 3" TO THE HORIZONTAL FOOT (7.5cm/30cm).
- 2. REINFORCED EPDM MEMBRANE SHALL BE INSTALLED PARALLEL WITH RIDGE LINE (WITH MEMBRANE CENTERED OVER THE RIDGE LINE) AS SHOWN.
- 3. FOR PROPER MEMBRANE ATTACHMENT AND SPLICING, REFER TO APPLICABLE WBRMA-2 DETAIL.
- REFER TO WEATHERBOND SPECIFICATIONS FOR REQUIRED NUMBER OF PERIMETER SHEETS, SHEET WIDTH AND MEMBRANE FASTENING DENSITY.
- 5. HPWX FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
- 6. AS AN OPTION, 9" (23cm) WIDE PEEL & STICK RPS MAY BE USED BENEATH EPDM FIELD SHEETS FOR PERIMETER SECUREMENT.



RIDGE MEMBRANE **ATTACHMENT** 



SEE NOTE

0

MECHANICALLY ATTACHED EPDM

WBRMA-22