

WeatherBond EPDM

20" Peel & Stick Cured Flashing



Overview

WeatherBond EPDM 20" Peel & Stick (P&S) Cured Flashing is pre-cut 20" wide with P&S Seam Tape already applied and offers an effective, labor-saving way to flash a curb. Production time on projects with numerous curbs or wall flashings can be reduced with this productivity boosting accessory.

Features and Benefits

- Pre-cut 20" wide with full width of P&S Seam Tape already applied
- Provides up to 70% time savings for flashing curbs and walls
- Can also be used as a target membrane in pipe details: WBRC-8.1A, WBRMA-8.1, and WBRMA-8.2
- Available in 20" x 50' rolls of cured 60-mil EPDM flashing

Installation

1. Attach deck membrane at the curb according to specific WeatherBond system details and secure at angle change.
2. Cut a piece of P&S Cured Flashing equal in length to the perimeter of the curb plus 3" minimum (i.e. a 2' x 2' curb would require an 8' 3" length of P&S Cured Flashing).
3. Cut the width of the P&S Cured Flashing to match the height of the curb plus 6" for the splice and 2" to go over the top of the curb. (Width = curb height + 8").
4. The entire surface where the P&S Cured Flashing will be applied must be clean. The adhesive on the back of the P&S Cured Flashing will not adhere to dusted or dirty surfaces. Any residual contamination will be detrimental to the bond strength of the adhesive.
5. Place the P&S Cured Flashing on a flat surface with the tape side up and the release liner intact.
6. Apply WeatherBond EPDM Primer to the curb and to the splice area on the deck membrane.
7. After the EPDM Primer has flashed off properly, bond the P&S Cured Flashing to the curb. Wrap the entire curb, leaving the deck flange folded upwards with the release liner still in place. Care should be taken not to stretch the P&S Cured Flashing.
8. To complete the splice between the P&S Cured Flashing and the deck membrane, cut the P&S Cured Flashing at each corner of the curb, allowing the P&S Cured Flashing to fall in place. Round all cut corners. Press the P&S Cured Flashing into the angle change as possible.
9. With the tape adhesive lying flat on the primed surface, remove the release liner by pulling it out from beneath the P&S Cured Flashing while simultaneously pressing the tape onto the primed surface using firm, even hand pressure across the splice towards the splice edge. Immediately roll the splice with a 2" (50 mm)-wide roller, using positive pressure.
10. Broom the mated P&S Cured Flashing over the curb to ensure proper mating of the pressure-sensitive adhesive.
11. Make the vertical splice in the P&S Cured Flashing as per WeatherBond WBRC-2.1A details.
12. Flash the corners of the curb as per WeatherBond WBRC-15 details.

REVIEW CURRENT WEATHERBOND INSTALLATION INSTRUCTIONS FOR SPECIFIC INSTALLATION REQUIREMENTS.



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

Precautions

1. Avoid prolonged contact with skin. In case of contact with skin, thoroughly wash affected area with soap and water.
2. WeatherBond EPDM Primer must be used when installing P&S Cured Flashing.
3. P&S Cured Flashing must be stored in a dry area. In warm, sunny weather, keep P&S Cured Flashing in the box in a shaded area until ready for use.
4. Due to solvent flash-off, condensation may form on freshly applied primer when the ambient temperature is near the dew point. If condensation develops, the application of Primer and installation of P&S Cured Flashing must be discontinued, as proper adhesion will not be achieved. Allow the primed surface to flash-off and apply a thin freshener coat of primer to the previously coated surface when conditions allow.
5. Jobsite storage temperatures in excess of 90°F (32°C) will shorten product shelf life. Prolonged jobsite exposure to temperatures below 40° (4°C) will cause the adhesive to lose tack and, in extreme cases, will not bond to the EPDM membrane. If this situation is encountered, move P&S Cured Flashing to a warm area and allow it to return to a minimum of 60°F (15°C).
6. In order to achieve proper adhesion to the deck membrane when installing P&S Cured Flashing at temperatures below 40°F (5°C), heat the primed area of the deck membrane with an with air gun as the tape adhesive is applied and pressed into place.
7. Do not allow waste products (petroleum, grease, oil, solvents, vegetable or mineral oil, animal fats, etc.) or direct steam venting to come in contact with the P&S Cured Flashing.
8. KEEP OUT OF THE REACH OF CHILDREN

Typical Properties and Characteristics

Property	Results
Base	Membrane - EPDM Adhesive-Synthetic Polymers
Thickness	Membrane - 60 mil (1.52 mm)
Size	20" x 50' (508 mm x 15.2 m)
Packaging	50 lf/carton (15.2 m) - 1 roll/carton
Weight/Carton	50 lbs. (22.7 kg)
Shelf Life	1 year
Part Number	327533

Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.

LEED® Information

Pre-consumer Recycled Content	0%
Post-consumer Recycled Content	0%
Manufacturing Location	Greenville, IL
Solar Reflectance Index (SRI)	N/A



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

P.O. Box 251 | Plainfield, PA 17081 | 866.471.5125 | FAX: 717.960.4034 | www.weatherbondroofing.com

© 2022 WeatherBond. 06.28.22 WB-8439 - "EPDM 20" Peel & Stick Cured Flashing Technical Data Bulletin"
WeatherBond is a trademark of WeatherBond.