




WeatherBond™ Pro ROOFING SYSTEM



1. ALLOW 1/4" GAP BETWEEN
ADJOINING SECTIONS OF
COATED METAL.



2. INSTALL 2" (50 mm) WIDE DUCT
TAPE OVER JOINT IN COATED
METAL.



3. HEAT WELD 6" (150 mm) WIDE
PIECE OF NON-REINF.
MEMBRANE OVER JOINT.

NOTES:

1. APPROXIMATELY 1/8" (3 mm) DIAMETER BEAD OF CUT-EDGE SEALANT IS REQUIRED ON CUT EDGES OF REINFORCED MEMBRANE.
2. A COUNTERFLASHING TERMINATION MAY BE USED IN LIEU OF METAL CAP FLASHING. REFER TO DETAIL WBPC-9.3.
3. PLACE A LAYER OF WEATHERBOND PRO MEMBRANE UNDER THE METAL CAP TO PROTECT AGAINST MOISTURE INFILTRATION AT JOINTS.

WBPC-12.3
COATED METAL WALL FLASHING

WEATHERBOND™
© 2007 WEATHERBOND