


## NOTES:

- 1. REFER TO TABLES ON SHEETS
  ATTACHMENT 1-2 FOR
  DETAILED INSPECTION,
  CLEANING AND PRIMING FOR
  DIFFERENT MATERIALS WITHIN
  THE FLASHING AREAS.
- 2. IF FLUTES ARE
  PERPENDICULAR DRILL A 3/8"
  (1cm) WEEP HOLE IN THE
  BOTTOM FLUTES OF THE
  STEEL DECK ALONG THE TIE
  IN.



PRE-PUNCHED\_



TIE-IN: TPO OR PVC MEMBRANE INTO EXISTING ACCEPTABLE ROOFS WITH METAL DECK (PAGE 1 OF 2)

