


NOTES:

1. REMOVE ALL GRAVEL AT TIE-IN.
2. DRILL A 3/8" (10mm) DIAMETER WEEP HOLE INTO THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE PERIMETER TO THE TIE-IN 6" (152mm) MINIMUM TO 12" (305mm) MAXIMUM FROM THE SEAM FASTENING PLATE.
3. ON MECHANICALLY ATTACHED SYSTEMS, HPWX FASTENERS AND PLATES ARE REQUIRED OVER STEEL DECKS.
4. IF WATER PONDS OR FLOWS OVER TIE-IN FROM BUR SURFACE, WEATHERBOND ROOFING SYSTEM MUST BE TOTALLY ISOLATED; SEE [DETAIL WBPC-13.2](#).

DIMENSIONS	mm		
(A)	6"	152	MIN.
(B)	2"	51	± 1/2" (13mm)
(C)	6"	152	TO
	12"	305	

TPO ONLY
(NOT FOR PVC)



TPO TIE-IN TO BUILT-UP ROOFING OVER STEEL ROOF DECK

- TPO MEMBRANE
- APPROVED SUBSTRATE
- 0 — SEE NOTE

THERMOPLASTIC ROOFING SYSTEM

WBPC-13.1