



NOTES:

1. PEEL & STICK RPS MAY BE INSTALLED INTO THE STRUCTURAL DECK. ON MECHANICALLY-FASTENED ROOFING SYSTEMS, HPWX FASTENERS AND POLYMER SEAM PLATES ARE REQUIRED OVER STEEL DECKS.
2. ALL VERTICAL FIELD SPLICES AT THE BASE OF A WALL OR CURB MUST BE OVERLAID WITH A PEEL & STICK T-JOINT COVER OR A 6"X6" (152mm X 152mm) SECTION OF PEEL & STICK UNCURED EPDM FLASHING CENTERED OVER THE FIELD SPLICE. PROJECTS USING 90-MIL MEMBRANE, ALL VERTICAL SPLICES MUST BE OVERLAID WITH A T-JOINT COVER AND COVERED WITH A 12"X12" (305mm X 305mm) PEEL & STICK UNCURED EPDM FLASHING PIECE OR T-JOINT COVER. BOTH LAYERS SHALL BE CENTERED AND SEALED WITH CONTINUOUS LAP SEALANT. REFER TO [DETAIL WBRC-2.3](#).
3. EPDM PRIMER MUST BE APPLIED TO BACK SIDE OF DECK MEMBRANE PRIOR TO COMPLETING SPLICE TO PEEL & STICK RPS.
4. WHEN MECHANICAL FASTENERS ARE USED TO PENETRATE THE METAL COUNTER-FLASHING, USE EPDM WASHERS, APPLY WATER CUT-OFF MASTIC UNDER THE COUNTER-FLASHING OR CAULK THE FASTENER HEADS.
5. WHEN THE USE OF PEEL & STICK RPS AND CONTINUOUS MEMBRANE IS NOT FEASIBLE, ACCEPTABLE FLASHING SHALL CONFORM TO THERMOSET UNIVERSAL [DETAIL WBRC-12.3](#).



SHEAR/EXPANSION COVER	EPDM MEMBRANE
	APPROVED SUBSTRATE
	SEE NOTE

EPDM ROOFING SYSTEM
WBRC-3.3