




A

INSTALL COATED SHEET METAL STRIPS WITH THREADED FASTENERS. REFER TO TABLES ON SHEETS [LF-A TO C](#) FOR DETAILED INSPECTION, CLEANING AND PRIMING FOR DIFFERENT MATERIALS WITHIN THE FLASHING AREAS.



B

PROPERLY CLEAN WITH MEMBRANE CLEANER PRIOR TO WELDING.



C

WELD TPO OR PVC MEMBRANE TO COATED METAL STRIP.




D

USE SAND PAPER GRIT # 60 TO ABRABE THE AREAS TO WHICH THE LIQUISEAL LIQUID FLASHING RESIN WILL BE APPLIED.



E

THOROUGHLY CLEAN THE TIE-IN AREA.



F

CUT TWO PIECES OF [LIQUISEAL Flashing Fleece](#), (FOR DIMENSIONS SEE [13.2A](#)).



G

APPLY PAINTER'S TAPE ALONG TIE-IN EDGE.




H

THOROUGHLY MIX THE RESIN, PER PUBLISHED INSTRUCTIONS.



INSTALL BOTH LAYERS OF PRE-CUT [LIQUISEAL Flashing Fleece](#), EMBEDDED IN RESIN (SEE [LF-13.2A](#)).




J

REMOVE TAPE IMMEDIATELY ENSURING THAT RESIN EXTENDS 1/4" - 1/2" (1-1.5cm) BEYOND EDGE OF FLEECE.



TIE-IN: TPO OR PVC MEMBRANE INTO EXISTING ACCEPTABLE ROOFS WITH METAL DECK (PAGE 2 OF 2)



LIQUID FLASHING
LF-13.2B