



**STEP 1** AFTER INSPECTION, PREPARATION & CLEANING PER SHEET LF-A TO E, APPLY BASE LAYER OF **LIQUISEAL Liquid Flashing Resin**, PER PUBLISHED COVERAGE RATE

**STEP 2** IMMEDIATELY PRESS **LIQUISEAL Flashing Fleece**, INTO THE APPLIED LIQUISEAL Liquid Flashing Resin TAKING CARE AT CORNERS AND CREVICES

**STEP 3** FOR EACH LAYER OF FLEECE APPLY A 2ND (TOP) COAT OF **LIQUISEAL Liquid Flashing Resin**, PER PUBLISHED COVERAGE RATE ENSURING THE FLEECE IS COMPLETELY SATURATED

REFER TO APPLICABLE SMACNA DETAILS (LATEST EDITION)

WATERPROOF SHEET METAL SCUPPER BOX ASSEMBLY **2** (BY OTHERS)

SEALANT (BY OTHERS)

EPDM/TPO/PVC (REFER TO SUBSTRATE PREPARATION TABLE ON SHEET LF-A)

**NOTES:**

1. REFER TO TABLES ON SHEETS **ATTACHMENT 1-2** FOR DETAILED INSPECTION, CLEANING AND PRIMING FOR DIFFERENT MATERIALS WITHIN THE CONSTRUCTION AREA.
2. WOOD NAILER MUST EXTEND PAST TOTAL WIDTH OF SHEET METAL FLANGE.
3. MECHANICAL FASTENERS MUST BE SECURED INTO STRUCTURAL CONCRETE, SOLID MASONRY OR PRESSURE TREATED WOOD BLOCKING.

**(B)** FLEECE MUST BE COVERED 1/4" - 1/2" (1cm - 1.5cm) AT ALL EDGES

DIMENSIONS		cm	
(A)	3"	7.5	MIN.
(B)	1/4"	1	TO
	1/2"	1.5	



THROUGH-WALL SCUPPER

- ROOF MEMBRANE
- LIQUISEAL Flashing Fleece
- LIQUISEAL Liquid Flashing Resin
- SEE NOTE(S)

LIQUID FLASHING  
**LF-18.1**