


- 1. CUT HOLES IN EXISTING HIGH EAVE TRIM AT TOP TO REDIRECT VENTING. SPECIFIER TO CALCULATE THE VENT SIZES, FREQUENCY OF HOLES WITHOUT WEAKENING THE EXISTING SHEET METAL.
- 2. FOR ADDITIONAL INFORMATION REFER TO MR Z1.1 & MR Z1.2 AT THE END OF THIS SECTION.
- SHEET METAL SCREWS @ 6" O.C., MAX., EXPOSED 3/4" (2cm) MIN. BEYOND EXISTING SHEET METAL SUBSTRATE
- D FASTENERS TO MATCH EXISTING @ 6"
 O.C., MAX., EXPOSED 3/4" (2cm) MIN.
 BEYOND EXISTING SUBSTRATE



HIGH-END VENTED ROOF EDGE



SEE NOTE(S)

METAL RETROFIT MR | T1.8