


NOTES:

1. REMOVE ALL GRAVEL AT TIE-IN.
2. OVERLAY UNCURED EPDM FLASHING WITH 6"(15cm) PEEL & STICK FLASHING TO REDUCE HEAT GAIN ON TPO MEMBRANE
3. IF FLUTES ARE PERPENDICULAR TO THE TIE-IN DRILL A 3/8" (1cm) DIAMETER WEEP HOLE INTO THE BOTTOM FLUTES OF THE STEEL DECK ALONG THE PERIMETER TO THE TIE-IN 6" (15cm) MINIMUM TO 12" (30cm) MAXIMUM FROM THE SEAM FASTENING PLATE.
4. ON MECHANICALLY ATTACHED SYSTEMS, HPWX FASTENERS AND PLATES ARE REQUIRED OVER STEEL DECKS.
5. IF WATER PONDS OR FLOWS OVER TIE-IN FROM BUR SURFACE, WEATHERBOND ROOFING SYSTEM MUST BE TOTALLY ISOLATED; SEE [DETAIL WBPC-13.2](#).

DIMENSIONS	cm	
(A)	6"	15 MIN.
(B)	2"	5 ± 1/2" (1.5cm)
(C)	6"	15 TO
	12"	30

TPO ONLY  
(NOT FOR PVC)



TPO TIE-IN TO BUILT-UP ROOFING OVER STEEL ROOF DECK

- TPO MEMBRANE
- APPROVED SUBSTRATE
- 0 SEE NOTE

THERMOPLASTIC ROOFING SYSTEM

WBPC-13.1