


NOTES:

1. REMOVE ALL EXISTING LEAD AND FLASHING MATERIAL BEFORE INSTALLING PRE-FABRICATED SQUARE TUBE WRAP.

FASTENER

- 2. TEMPERATURE OF THE TUBE PENETRATION MUST NOT EXCEED 140°F (60°C) WHEN USING PVC AND 160°F (71°C) WHEN USING TPO FLASHING.
- 3. WEATHERBOND FASTENERS & SEAM FASTENING PLATES FOR MECHANICALLY FASTENED SYSTEM (NOT REQUIRED ON ADHERED SYSTEM). SEE TABLE ABOVE.
- 4. T-JOINT COVERS ARE NOT REQUIRED ON STANDARD COLORS (WHITE, TAN, GRAY), FOR ADDITIONAL COLORS IT IS REQUIRED TO COVER T-JOINTS





FIELD—FABRICATED SQUARE TUBE FLASHING WEATHERBOND
THERMOPLASTIC
REINFORCED MEMBRANE
APPROVED SUBSTRATE

SEE NOTE

THERMOPLASTIC ROOFING SYSTEM

WBPC-8.4