




FASTEN MEMBRANE AND FLASH CURB OR WALL WITH CURED EPDM MEMBRANE FOLLOWING STANDARD PROCEDURES USING BONDING ADHESIVE and PAS SEAM TAPE.





AFTER APPLYING EPDM PRIMER, REMOVE AND REPLACE POLY BACKING. FOLD 9"x9" (23cm x 23cm) FLASHING IN HALF WITH ROUNDED PORTION TURNED UP. CENTER FLASHING ON CORNER AND FIRMLY PRESS AGAINST VERTICAL SURFACE.



ROLL AND CREASE FLASHING TIGHTLY INTO ANGLE CHANGE AND FIRMLY ROLL FLASHING ONTO THE DECK MEMBRANE.

| 5 | LAP SEALANT | | | |
|---|-------------|-----------|----------|-------|
| _ | | | | |
| _ | | | | |
| , | | A (1 T) A | TWO INCL | \\#5E |

AFTER ADHERING, ROLL WITH A TWO INCH WIDE STEEL HAND ROLLER. PAY PARTICULAR ATTENTION TO THE STEP OFFS AND ANGLE CHANGES.


| DIME | NSIONS | cm | |
|------|--------|----|----|
| A | 6" | 15 | ТО |
| | 9" | 23 | |

NOTES:

- 1. FOR PROJECTS USING 90-MIL MEMBRANE, REFER TO DETAIL WBRC-15.8 FOR REQUIRED FLASHING ENHANCEMENTS.
- 2. A HEAT GUN MUST BE USED WHEN FORMING PEEL & STICK UNCURED EPDM FLASHING IN COLDER TEMPERATURES,



OUTSIDE CORNER WITH PEEL & STICK UNCURED EPDM FLASHING (OPTION 2)



· LI DIVI WILIVIDITAN

→ APPROVED SUBSTRATE

O → SEE NOTE

EPDM ROOFING SYSTEM

WBRC-15.7