

1

FASTEN MEMBRANE AND FLASH CURB OR WALL WITH CURED EPDM MEMBRANE FOLLOWING STANDARD PROCEDURES USING BONDING ADHESIVE AND PAS SEAM TAPE AT MEMBRANE SPLICE.

2

PEEL & STICK UNCURED EPDM FLASHING 6"X6" (15X15cm)

CENTER FOLD LINE

USE PRE-CUT T-JOINT COVERS OR CUT A 6"x6" (15X15cm) & 12"x12" (30X30cm) SECTION OF PEEL & STICK UNCURED EPDM FLASHING AND ROUND CORNERS

3

CLEAN THE DRY SPLICE AREA OF THE EPDM WITH EPDM PRIMER

4

POLY FILM

REMOVE & REPLACE POLY BACKING ON FLASHING. FOLD 6"X6" FLASHING IN HALF WITH ROUNDED PORTION TURNED UP. CENTER ON CORNER & FIRMLY PRESS AGAINST VERTICAL SURFACE

5

ROLL & CREASE FLASHING TIGHTLY INTO ANGLE CHANGE & FIRMLY ROLL FLASHING ONTO THE DECK MEMBRANE

USE HEAT GUN TO WARM THE FLASHING IN COLD WEATHER

6

AFTER ADHERING, ROLL WITH A TWO INCH WIDE STEEL HAND ROLLER. PAY PARTICULAR ATTENTION TO THE STEP OFFS AND ANGLE CHANGES

7

ROLL STEP OFFS AND ANGLE CHANGES

8

APPLY EPDM PRIMER TO THE SPLICE AREA. INSTALL THE 12"X12" (30X30cm) SECTION OF PEEL & STICK UNCURED EPDM FLASHING CENTERED OVER PREVIOUSLY APPLIED FLASHING.

9

SEAL ALL EDGES WITH LAP SEALANT AS SHOWN



OUTSIDE CORNER FLASHING FOR PROJECTS WITH 90-MIL MEMBRANE

- EPDM MEMBRANE
- APPROVED SUBSTRATE
- SEE NOTE

EPDM ROOFING SYSTEM

WBRC-15.8