



NOTES:

1. ALL BOLTS OR CLAMPS MUST BE IN PLACE TO PROVIDE CONSTANT COMPRESSION ON WATER CUT-OFF MASTIC.
2. REMOVE EXISTING LEAD, FLASHING MATERIAL & ENSURE THE DRAIN RING IS COMPLETELY CLEAN DOWN TO BARE METAL.
3. USE DETAIL [WBRMA-6.0](#) FOR MECHANICALLY-FASTENED SYSTEMS.
4. THE HOLE IN THE MEMBRANE SHALL EXCEED THE DIAMETER OF THE DRAIN PIPE, BUT SHALL BE NO LESS THAN 1/2" (1.5cm) FROM THE ATTACHMENT POINTS OF THE DRAIN CLAMPING RING.
5. ROOF DRAIN SIZE AND NUMBER OF DRAINS SHALL BE IN ACCORDANCE WITH THE LOCAL CODES.
6. FIELD SPLICES MUST BE LOCATED AT LEAST 6" (15cm) OUTSIDE THE DRAIN SUMP.
7. WEATHERBOND RECOMMENDS THE DRAIN TARGET SPLICE BE SHINGLED
 - 7.1. CUT A SQUARE HOLE IN THE FIELD SHEET TO BE AT LEAST 6" (15cm) OUTSIDE THE DRAIN SUMP
 - 7.2. APPLY PRIMER AND PAS SEAM TAPE TO THE BOTTOM OF THE FIELD SHEET
 - 7.3. PRIME THE TARGET PIECE OF NR EPDM
 - 7.4. MATE THE TARGET TO THE TAPE
 - 7.5. APPLY BONDING ADHESIVE TO ADHERE FIELD AND TARGET MEMBRANE TO THE SUBSTRATE



ROOF DRAIN – REINFORCED FIELD SHEET WITH SUMP EXCEEDING 3" PER FOOT	<ul style="list-style-type: none"> —● EPDM MEMBRANE APPROVED SUBSTRATE 0 SEE NOTE
--	---

EPDM ROOFING SYSTEM
WBRC-6.2