



NOTES:

1. SLEEPER MUST BE LARGE ENOUGH TO SUPPORT WEIGHT OF EQUIPMENT WITHOUT INDENTING INSULATION. EXTEND WOOD NAILER OUT AS REQUIRED BY STRUCTURAL ENGINEER TO DISTRIBUTE SUBJECT LOAD OR AT LEAST EXTEND OUT MIN. 3" (7.5cm).
2. ENSURE SCREW/ANCHOR HEADS IN TOP SURFACE OF WOOD BLOCKING ARE RECESSED TO PROTECT MEMBRANE.
3. WOOD NAILERS NOT REQUIRED UNDER PIPE SUPPORTS.
4. CONSULT STRUCTURAL ENGINEER AND/OR SPECIFIER TO AVOID WATER PONDING DUE TO DECK DEFLECTION.



SLEEPER	<ul style="list-style-type: none"> <li><span style="color: blue;">—</span> • EPDM MEMBRANE</li> <li> • APPROVED SUBSTRATE</li> <li><span style="border: 1px solid red; padding: 2px;">0</span> • SEE NOTE</li> </ul>
---------	--

EPDM ROOFING SYSTEM
WBRC-24.0