


WeatherBond EPDM

White Peel & Stick T-Joint Covers



Overview

Let WeatherBond simplify your next EPDM installation with their EPDM White Peel & Stick (P&S) T-Joint Covers. The 6" P&S T-Joint Cover combines 60 mil (2.4 mm), uncured EPDM flashing laminated to 30-mil (0.75 mm), fully cured P&S adhesive providing 90 mils (3.5 mm) of total thickness.

P&S T-Joint Covers are used to seal field splice intersections, horizontal-to-vertical transitions of field splices, and 30-year outside corner details on WeatherBond EPDM white membrane roofing systems.

Features and Benefits

- Available in 6" x 6"
- Pre-cut flashing with rounded corners increases installation speed by eliminating the need for cutting
- Combine with WeatherBond EPDM white 20" Peel & Stick Cured Flashing for maximum productivity and a cleaner, more uniform appearance across the roof
- Approved for use on EPDM and TPO membranes



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

Installation

1. The entire surface where the P&S T-Joint Cover will be applied must be clean. The adhesive on the back of the P&S T-Joint Cover will not adhere to dusted or dirty surfaces. Any residual contamination will be detrimental to the bond strength of the adhesive.
2. Remove dirt and excess dust from the splice area by wiping with a clean rag. If necessary, clean the splice area thoroughly with Weathered Membrane Cleaner and allow to dry completely before proceeding.

Note: Permeation-resistant gloves (that meet ANSI/ISEA 105-2005) are required for hand protection when cleaners or primers are being used.

3. Application of Multi-Purpose Primer, TPO Primer, or Low-VOC Primer
 - a. Standard Membrane - Apply the primer with a clean Splice Wipe (or equivalent). Scrub the area of the membrane (where the P&S T-Joint Cover is to be applied) in a circular motion to achieve a thin, even coating on the membrane. The properly cleaned/primed area will be uniform in color without streaks and free of globs or puddles.

Note: Membrane type determines which primer to use. TPO Primer is used with TPO, Multi-Purpose Primer is used with EPDM, and Low-VOC Primer can be used with both TPO and EPDM.

- b. Non-Reinforced (No Dust) EPDM or TPO Membrane - Roller-apply the primer to the membrane with a short nap-length paint roller. The coated area will be free of globs or puddles.

Note: The use of excessive amounts of primer will not significantly enhance the adhesion of the P&S T-Joint Cover to the membrane. Use only the amount necessary to obtain 100% coverage of the area where the P&S T-Joint Cover will be applied.

4. For EPDM systems only, apply a $\frac{5}{16}$ "-diameter (8 mm) bead of WeatherBond EPDM White Lap Sealant $\frac{1}{2}$ " (13 mm) in each direction from the membrane intersection according to detail WBRC-2.1.
5. Allow the primer to properly flash off until it does not transfer to a dry finger touch. Install the P&S T-Joint Cover as soon as the primer flashes off to minimize potential dust contamination and promote adhesion in colder weather.
6. Immediately roll the P&S T-Joint Cover with a 2"-wide (50 mm) roller, using positive pressure. **Carefully** roll the area where lap sealant was applied using light pressure.
7. To achieve proper adhesion of the P&S T-Joint Cover when jobsite temperatures fall below 40°F (4°C), heat the cleaned/primed area of the membrane with a hot-air gun as the flashing is applied and pressed into place.

REVIEW CURRENT WEATHERBOND INSTALLATION INSTRUCTIONS FOR SPECIFIC INSTALLATION REQUIREMENTS.

Precautions

- Avoid prolonged contact with skin. In case of contact with skin, thoroughly wash affected area with soap and water.
- Prolonged jobsite storage temperatures in excess of 90°F (32°C) will shorten product shelf life.
- In warm, sunny weather, keep P&S T-Joint Covers in their box in a shaded area until ready to use.
- Storage and use of P&S T-Joint Cover at temperatures below 40°F (4°C) will result in a loss of adhesive tack and, in extreme cases, will result in no bond to the substrate.
- P&S uncured EPDM must be stored in a dry area. It is recommended to store the flashing below 80°F (27°C) to ensure maximum formability and shelf life.
- P&S T-Joint Cover must be stored in a dry area.
- Due to solvent flash-off, condensation may form on freshly applied primer when the ambient temperature is near the dew point. If condensation develops, the application of primer and P&S T-Joint
- Cover must be discontinued as proper adhesion will not be achieved.
- Allow the surface to dry and apply a thin freshener coat of primer to the previously coated surface and apply P&S T-Joint Cover when conditions allow.
- Do not allow waste products (petroleum, grease, oil, solvents, vegetable or mineral oil, animal fats, etc.) or direct steam venting to come in contact with the P&S T-Joint Cover.
- **KEEP OUT OF THE REACH OF CHILDREN.**

Typical Properties and Characteristics

Sizes	6" x 6" (150 mm x 150 mm)
Color	White
Packaging	20/carton
Weight	3 lbs/carton (1.35 kg) for 6" x 6"
Shelf Life	9 months when stored between 60° and 80°F (15° to 27°C)

Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.

WeatherBond's Peel & Stick White Uncured EPDM Flashing meets or exceeds the minimum requirements set forth by ASTM D4811 for a Type 1 (EPDM) Class V (cures on the roof) flashing material.

LEED® Information

Pre-consumer Recycled Content	2%
Post-consumer Recycled Content	0%
Manufacturing Location(s)	Greenville, IL
Solar Reflective Index	N/A



WEATHERBOND
ROOFING SYSTEMS

Single-Ply Simplified

P.O. Box 251 | Plainfield, PA 17081 | 866.471.5125 | FAX: 717.960.4034 | www.weatherbondroofing.com

© 2021 WeatherBond. 04.01.21 WB-10106 - "White Peel & Stick T-Joint Covers Technical Data Bulletin"
WeatherBond is a trademark of WeatherBond. LEED is a registered trademark of the U.S. Green Building Council.