

# WeatherBond EPDM

## Peel & Stick White Curb Wrap



### Overview

Let WeatherBond simplify your next WeatherBond White EPDM installation with their Peel & Stick (P&S) White EPDM Curb Wrap. The most efficient means to flash a curb as membrane comes pre-cut 20" wide with 6" of WeatherBond's Peel & Stick Seam Tape already applied. Production time on projects with numerous curbs or wall flashings can be substantially reduced with this labor-saving accessory. P&S White EPDM Curb Wrap is ideal for flashing curbs and walls on all WeatherBond Roofing Systems.

### Features and Benefits

- Available in 20" x 50' rolls of cured 60-mil EPDM flashing
- Pre-cut 20" wide with 6" WeatherBond Peel & Stick Seam Tape already applied
- Provides up to 70% labor savings for flashing curbs and walls
- Cleaner appearance and stronger seams



**WEATHERBOND**  
ROOFING SYSTEMS

Single-Ply Simplified

### Installation

1. Attach deck membrane at the curb according to specific WeatherBond system details.
2. Cut a piece of P&S White EPDM Curb Wrap equal in length to the perimeter of the curb plus 3" minimum (i.e. a 2' x 2' curb would require a 8'-3" length of P&S White EPDM Curb Wrap).
3. For curbs where the deck membrane is fastened on the vertical, cut the width of the P&S White EPDM Curb Wrap to match the height of the curb plus 6" for the splice and 2" to go over the top of the curb. (Width = curb height + 8"). For curbs where the deck membrane is fastened on the horizontal, cut the width of the P&S White EPDM Curb Wrap to allow 3" of splice beyond the 2" fastening plates and 2" to go over top of the curb. (Width = curb height + 7").
4. Place the P&S White EPDM Curb Wrap on a flat surface with the tape side up and the release liner intact.
5. Apply WeatherBond's EPDM Bonding Adhesive to the curb and to the P&S White EPDM Curb Wrap.
6. While the bonding adhesive is drying, apply EPDM Primer to the splice area on the deck membrane.
7. After the bonding adhesive and primer have dried properly, bond the P&S White EPDM Curb Wrap to the curb. Wrap the entire curb, leaving the area containing the tape adhesive folded upwards with release liner still in place. Care should be taken not to stretch the P&S White EPDM Curb Wrap.
8. To complete the splice between the P&S White EPDM Curb Wrap and the deck membrane, cut the P&S White EPDM Curb Wrap at each corner of the curb, allowing the P&S White EPDM Curb Wrap to fall in place. Round all cut corners. Press the P&S White EPDM Curb Wrap into the angle change as tightly as possible.
9. With the tape adhesive laying flat on the primed surface, remove the release liner by pulling it out from beneath the P&S White EPDM Curb Wrap while simultaneously pressing the tape onto the primed surface using firm even hand pressure across the splice towards the splice edge. Immediately roll the splice with a 2" (50 mm)-wide steel roller, using positive pressure.
10. Broom the mated P&S White EPDM Curb Wrap over the curb to ensure proper mating of the bonding adhesive.
11. Make the vertical splice in the P&S White EPDM Curb Wrap as per WeatherBond WBRC-5 details.
12. Flash the corners of the curb as per WeatherBond WBRC-15 details.

REVIEW CURRENT WEATHERBOND INSTALLATION INSTRUCTIONS FOR SPECIFIC INSTALLATION REQUIREMENTS.

## Precautions

1. Avoid prolonged contact with skin. In case of contact with skin, thoroughly wash affected area with soap and water.
2. WeatherBond LC-60 Bonding Adhesive, Low-VOC Bonding Adhesive or Aquabase 120 Bonding Adhesive and EPDM Primer must be used when installing P&S White EPDM Curb Wrap.
3. P&S White EPDM Curb Wrap must be stored in a dry area. In warm, sunny weather, keep P&S White EPDM Curb Wrap in the box or in a shaded area until ready to use.
4. Due to solvent flash-off, condensation may form on freshly applied primer when the ambient temperature is near the dew point. If condensation develops, the application of Primer and installation of P&S White EPDM Curb Wrap must be discontinued, as proper adhesion will not be achieved. Allow the primed surface to dry and apply a thin freshener coat of Primer to the previously coated surface when conditions allow.
5. Jobsite storage temperatures in excess of 90°F (32°C) may affect product shelf life. Prolonged jobsite exposure to temperatures below 40°F (4°C) will cause the adhesive to lose tack and in extreme cases not bond to the EPDM membrane. If this situation is encountered, move P&S White EPDM Curb Wrap to a warm area and allow it to return to a minimum of 60°F (15°C).
6. In order to achieve proper adhesion to the deck membrane when installing P&S White EPDM Curb Wrap at temperatures below 40°F (5°C), heat the primed area of the deck membrane with a hot-air gun as the tape adhesive is applied and pressed into place.
7. Do not allow waste products (petroleum, grease, oil, solvents, vegetable or mineral oil, animal fats, etc.) or direct steam venting to come in contact with the P&S White EPDM Curb Wrap.
8. KEEP OUT OF THE REACH OF CHILDREN.

## Typical Properties and Characteristics

Property	Test Method
Size	20" x 50" (508 mm x 15.2 mm)
Base	Membrane - EPDM Adhesive - Synthetic Polymers
Thickness	Membrane - 60 mil (1.52 mm)
Packaging	50 lf/carton (15.2 m) - 1 roll/carton
Weight/Carton	30 lbs (13.6 kg)
Shelf Life	1 year

Typical properties and characteristics are based on samples tested and are not guaranteed for all samples of this product. This data and information is intended as a guide and does not reflect the specification range for any particular property of this product.



**WEATHERBOND**  
ROOFING SYSTEMS

Single-Ply Simplified

P.O. Box 251 | Plainfield, PA 17081 | 866.471.5125 | FAX: 717.960.4034 | [www.weatherbondroofing.com](http://www.weatherbondroofing.com)

© 2017 WeatherBond. 10.17.17  
WeatherBond is a trademark of WeatherBond.